

LAND ROVER 90/110 (NOT COUNTY) (1983 >)

DOG GUARD / GRILLE PROTECTRICE POUR CHIEN / HUNDEGITTER /
RIPARO PER CANI / DEFENSA PARA PERROS / HONDEREK

- Check kit contents against parts list below
- Read instructions fully before fitting guard

- Attach mounting feet (B) to dog guard (A) using thumbscrews (H) - refer to illustration overleaf
- Attach grey plastic sleeve (L) - refer to illustration overleaf
- Tilt and slide front seat
- Pass guard into vehicle making sure the mounting feet are anchored forward and resting on top of the bulkhead
- Making sure the guard is centralised, mark the rivet heads that are visible through the slots in the mounting feet
- Remove guard from vehicle
- Drill out the marked rivets using a 9mm (11/32") diameter drill
- Attach top bracket (J) onto locating tab on the top of the guard, making sure the angled face is rearwards
- Pass guard into vehicle and mount into vehicle using supplied fixings - refer to illustration overleaf
- Tighten all fixings
- Lift top bracket (J) until it contacts the headlining and mark 2 holes
- Drill through the headlining and roof channel using a 4.0mm diameter drill - **TAKE CARE NOT TO DRILL THROUGH ROOF**
- Fasten top bracket into position using self tapping screws (K)

NOTE: If an alarm is fitted, the sensor in the headlining must be moved. Locate aperture behind headlining approx 70mm up and 130mm forward of current position. Relocate sensor.

Parts list

A	1	Dog guard	
B	2	Mounting foot	
C	2	Stiffener plate	
D	4	M8 set screw	
E	4	M8 nut	
F	8	M8 flat washer	
G	4	M8 spring washer	
H	2	M8 thumbscrew	
J	1	Top bracket	
K	2	No. 10 self tapping screw	(discard on pre-1989 models)
L	1	Grey plastic sleeve	
M	2	Black plastic tube inserts	

LAND ROVER 90/110 (NOT COUNTY) (1983 >) DOG GUARD / GRILLE PROTECTRICE POUR CHIEN / HUNDEGITTER /
RIPARO PER CANI / DEFENSA PARA PERROS / HONDEREK

